


IPP-2066 VSWR

▶ Tr1 S11 Log Mag 10.00dB/ Ref 0.000dB [F1]




1 Start 100 MHz

IFBW 70 kHz


Stop 500 MHz Cor !

IPP-2066 Amplitude Balance, Phase Balance

Tr1 S21 Log Mag 600.0mdB/ Ref -3.000dB [RT D&M]




Tr2 S21 Phase 5.000°/ Ref -90.00° [RT D/M]



IPP-2066 Isolation

▶ Tr1 S21 Log Mag 10.00dB/ Ref -18.00dB [RT]



2 Start 100 MHz

IFBW 70 kHz

Stop 500 MHz Cor !